



ELECTRONIC CONTROL SYSTEM


NOTE:
 * 1 marked circuit is used in vehicles without immobilizer control system.
 * 2 marked circuit is used in vehicles with immobilizer control system.
 * 3 marked circuit is used in vehicles with EGR valve (stepper motor).
 * 4 marked circuit is used in vehicles with EGR vacuum switching valve.
 * marked terminal is a terminal which has been newly added or whose position has been changed due to installation of immobilizer control system.




MAF SENSOR




TP SENSOR



IGNITER



MAIN & FUEL PUMP RELAY



6E1-00550

6E1-00110